

Guardian Fire Shield™

FIRE SUPPRESSION SAFETY DEVICE

INSTALLATION GUIDE

STEP 1

Locate the ceiling joists and cut hole into space between joists. Centre in space if possible.



STEP 3

Adjust retaining arm for thickness of drywall.



STEP 5

GFS Base clip support.



STEP 7

This is how it should look when clip is installed. Clip should line up with the spray head.



STEP 2

Hole size must be 5 1/4" diameter (template provided). Cut with drywall saw.



STEP 4

Adjust for a tight fit.



STEP 6

Install base clip at end of extinguisher body otherwise you won't be able to get the assembly through the hole.



STEP 8

Feed the assembly through the hole, clip end first.



STEP 9

Continue to feed the assembly through the hole until it is completely in place.



STEP 11

Turn both locks 90 degrees while holding head in place. The arrow on the screw should be pointing away from the head.



STEP 13

Push in the two screw covers provided.



STEP 10

Once in place this is how it should appear.



STEP 12

Push the clips in place. Note that the clips have a taper. The wider side goes toward the center.



CONGRATS!

You have successfully completed installing your Guardian Fire Shield™.



Protect What Matters...
**WHEN EVERY
SECOND COUNTS**